



Protecting Your Adventure Lifestyle

Warrior Products, Inc.
16850 SW Upper Boones Ferry Rd
Ste. A
Durham, OR 97224
Phone (888) 220-6861
Fax (503) 692-0364
customerservice@warriorproducts.com

870 SAFARI REAR LIGHT BAR

INSTALLATION INSTRUCTIONS

07'+ JK WRANGLER & UNLIMITED

NOTE: Installation of this rear light bar system requires drilling through the body of the Jeep. If you are not confident of your abilities we recommend seeking out a professional installation facility. Due to welding, handling, shipping, etc., the light bar legs may need to be “adjusted” slightly (flexed inward or outward) to fit correctly. A small amount of twisting will not hurt the bar. Be careful not to scratch the paint as you install the legs.

1. Remove tail lights. Only the two screws closest to the tailgate need to be removed then the light housing will slide inward off the tub. Unplug the wires and set the lights aside.
2. One side at a time, hold the rear hoop leg supports against the Jeep tub and mark the holes for drilling through the tub. Position the rear mounting plate so that its top edge is even with the hard angled edge of the jeep tub just below the tub rail. The fore and aft positioning should be oriented so that the top two horizontal holes evenly straddle the vertical seam near the rear corner of the jeep tub. This should put the back edge of the rear bracket at approx. 1-5/8” rearward from the vertical body seam. Align the top edge of the forward leg mount plate along the hard edge below the tub rail as well.
3. Utilize a center punch and drill these marked locations with a 3/8” drill bit. We recommend starting the holes with a smaller sized drill bit and gradually working your way up to the 3/8” size. For the forward leg mounting plate position you’ll need to drill through both the outer body sheet metal and the interior sheet metal. Temporarily pull the carpet back from this area so the drill bit doesn’t grab the carpet and damage it. Once the forward leg mounting plate holes have been drilled, from the inside of the Jeep tub utilize a 1 inch hole saw and enlarge just the interior holes. This is so you can access the bolts with a socket wrench and short extension when the time comes to add the washers and nuts.
4. Now that all the holes have been drilled and deburred, utilize some touch up paint or primer and cover the exposed metal to prevent any future rust issues. Set the rear hoop leg supports back against the Jeep tub and install them using the 5/16” hardware provided. Hand-thread the nuts with washers on, but don’t tighten everything up just yet as this will help facilitate fitting of the hoop. Make certain there are washers against the inside of the sheet metal at all locations.
5. **NOTE:** If this assembly procedure includes the addition of a Safari Basket, install the basket onto the front and rear hoops at this time.
6. Set the rear light bar hoop unto the rear hoop leg supports and insert the snapper pins to hold them into place. For a more permanent install we recommend the use of the included 1/4” x 1 1/4” bolts, washers, and Nylock nuts. Orient the light tabs rearward.
7. Tighten the mounting hardware then plug in and reinstall the tail lights. Your installation is now complete.

If you need further assistance installing your product, please contact us by email at customerservice@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS

QUALITY



INTEGRITY



INNOVATION



SERVICE