



Protecting Your Adventure Lifestyle

Warrior, Inc.  
16850 SW Upper Boones Ferry Rd  
Ste. A  
Durham, OR 97224  
Phone: (888) 220-6861  
Fax: (503) 692-0364  
[sales@warriorproducts.com](mailto:sales@warriorproducts.com)  
[www.warriorproducts.com](http://www.warriorproducts.com)

---

## **97-01 Jeep Cherokee Rear Adventure Doors** **90852** **INSTALLATION INSTRUCTIONS**

### **Door Removal**

1. Start by rolling the windows down. Pulling the rubber boot of each door loose at the door jamb will expose the wiring. If you have manual doors and locks, you may see only two wires for speakers. If you have power doors, you will see several wires for the windows, locks, and speakers. To disconnect these wires you will need access the plug within the metal structure at the base of the 'B' pillar. Remove the plastic trim covering this area and you should be able to see and reach down inside to access the connection. The plug will have a locking tab that needs to be depressed as you're disconnecting them. Once apart, pull the wiring completely out of the door jamb.
2. Next, use a punch and small hammer, or a pair of pliers to remove the pin that holds the door stop to the door jamb. Push the door stop into the door to its' first 'detent' and replace the pin into the fitting at the door jamb. Tap it down so it doesn't fall out.
3. Now you can remove your door. Remove the 6 Torx bolts from the door and gently set the door aside. Make sure you keep the shims from each hinge labeled so you can put them back in the same orientation. This will be crucial to getting the doors re-aligned later. It may also be helpful to mark around them with a marker or paint pen so you have some reference when installing them again.

### **Tube Door Installation**

1. Install the paddle handle into your new doors. The paddle handles are attached using the 4 small Philips screws and nuts that are supplied in the kit. If you purchased mesh covers, these need to be fitted before the paddle handles are installed.
2. Bolt the door into place with the supplied button head allen hardware. Place the bolts through the hinges first then set the tube door mounting plate onto the threads. The mounting plate holes are oblong for fine tuning the doors' positioning within the door jamb.



Protecting Your Adventure Lifestyle

Warrior, Inc.  
16850 SW Upper Boones Ferry Rd  
Ste. A  
Durham, OR 97224  
Phone: (888) 220-6861  
Fax: (503) 692-0364  
[sales@warriorproducts.com](mailto:sales@warriorproducts.com)  
[www.warriorproducts.com](http://www.warriorproducts.com)

---

Snubbers:

1. Included in your kit are two rubber snubbers with associated washers and screws. These are a universal part to help assist you in controlling door rattle.
2. Locate a suitable location for the snubber to attach to the tube door and mark for drilling.
3. Drill the hole with a 1/8" drill bit.
4. Use the #8 sheet metal screws provided to pre-thread the hole then remove.
5. Using the same screws, add the small washer and secure the snubber to the door. Tighten the screw so that the washer is pulled into the snubber, but do not over-tighten or you'll risk going right through the snubber.
6. The image to the right illustrates a sample positioning of the rubber snubber, but you should locate it to best suit your needs.



**This completes your tube door installation. We hope you enjoy your new Warrior Product!**

If you need further assistance installing your product, please contact us by email at [techsupport@warriorproducts.com](mailto:techsupport@warriorproducts.com) or call us at (888) 220-6861.

**THANK YOU FOR PURCHASING WARRIOR PRODUCTS**

**QUALITY • INTEGRITY • INNOVATION • SERVICE**