


Warrior Products, Inc.

**SPRING OVER CONVERSION KIT**  
INSTALLATION INSTRUCTIONS

**WAR 4600, 4605, 4610, 4615**

YOUR KIT SHOULD CONTAIN THE FOLLOWING PARTS:

- 
- 2 UNIVERSAL SHOCK MOUNTS
  - 2 SPRING PERCHES
  - 2 P-19 SHOCKBOLTS
  - 2 UNIVERSAL U-BOLT PLATES
  - 2 COUPLER NUTS

Installation Instructions are **not** provided due to the multitude of variables that come into play when performing a spring over conversion. If you are not a qualified mechanic, or do not have access to necessary expertise, you should not attempt this conversion. You may need the assistance of your local 4X4 installer or service center.

.....  
*“Your Knight in Shining Armor!”*