

.....  
**Warrior, Inc.**

# **BACK PLATES**

## **DIAMOND PLATE / STEEL**

All “BACK PLATES” are designed to be placed over the existing metal surface under the tailgate area.

- 1) **Be sure that the surface is flat before installing your Back Plate. A little body work may be needed. Be sure any bare metal surfaces are painted.**
- 2) **Lift the Back Plate up to the area under the tailgate and use it to determine where you want to place your mounting holes. Mark the mounting locations with a felt pen or other marker and remove for ease of drilling. If you are covering rust or damaged areas, try not to locate any mounting holes in these areas.**
- 3) **If using the “pop” rivets provided to attach your Back Plate, you will need to secure a drill, a 3/16” drill bit, and a “pop” rivet tool. Drill your mounting holes using the 3/16” drill bit.**
- 4) **Place your drilled Back Plate in location and mark through the holes onto the body. Drill mounting holes where indicated using your 3/16” bit. Be careful not to drill through anything that may be behind the body metal.**
- 5) **Install the Back Plate using the “pop” rivets supplied. If you prefer you can use self tapping bolts to install the plate.**

**CONGRATULATIONS! You have finished your installation. Enjoy your new Warrior Products Back Plate and be sure to look for other quality Warrior Products for your vehicle.**

.....  
*“Your Knight in Shining Armor!”*