



Warrior, Inc.  
16850 SW Upper Boones Ferry Rd.  
Suite A  
Durham, Oregon 97224  
(503) 691-8915 Main  
(503) 692-0364 Fax  
(888) 220-6861 Toll Free  
[techsupport@warriorproducts.com](mailto:techsupport@warriorproducts.com)

---

## DIAMOND PLATE / STEEL CORNERS

All “CORNERS” are designed to be placed over the existing factory metal body. During shipping and handling your aluminum corners may be slightly altered but diamond plate aluminum is easy to work with. Make any slight modification needed to enhance their fit.

Because all body tubs are not built the same, some small modifications to the Corners may be required for a proper fit.

Rivets are supplied for mounting your corners to the body tub. If you prefer, you can use self tapping screws.

You do not need to seal behind the Corners as the Aluminum will not corrode and the steel versions are powder coated to protect against rust. You may want to spray any exposed metal with primer before installing your Corners.

1. Remove all tail lights, side markers, the gas tank rubber filler housing, and any other items that may be in the way of the installation process. If your Corners do not have precut holes, you will need to decide what parts and accessories you'll want to reinstall on your vehicle and then cut openings as needed.
2. Hold your Corners in place and mark where you need to add a hole or cut away material.  
Note: A hacksaw or saber saw with a “metal” blade will work well for this process.  
Complete all prep work, if any is needed, before installing your Corners.
3. If using the “pop” rivets provided to attach your Corners, you will need to secure a drill, a 3/16” drill bit, and a “pop” rivet tool. Drill your mounting holes using the 3/16” drill bit.
4. Lift your Corners into place. Drill your “pop” rivet holes starting near the tailgate and working around to the front of the vehicle. The holes should be about 12” apart. Be careful not to damage anything that may be behind the sheet metal you are drilling through.
5. Install the Corners using the “pop” rivets provided. Be sure to press your Corners into place as you work around from the rear towards the front for best fit.
6. Repeat the process described above for the other side.

If you need further assistance installing your product, please contact us by email at [techsupport@warriorproducts.com](mailto:techsupport@warriorproducts.com) or call us at (888) 220-6861.

**THANK YOU FOR PURCHASING WARRIOR PRODUCTS**

**QUALITY • INTEGRITY • INNOVATION • SERVICE**